

Basic DJ set I (CD): €25

Rodec MX-180 MKII & Denon DN-D4500



Basic DJ set II (CD - USB): €30

Rodec MX-180 MKIII & Denon DN-D4500 MKII



Extended basic DJ set III (CD - USB - Vinyl): €50

Rodec MX-180 MKIII & Denon DN-D4500 MKII & 2 * Synq X-TRM I



Pro DJ set IV (Vinyl - CD - USB): €90

Rodec MX-180 MKIII & Denon DN-D4500 MKII & 2 * Technics SL-1210MK7



Pro (USB - SD) DJ set V: €100

Denon DJ X-1800 & 2 * Denon DJ SC-5000 (USB - SD)



Pro USB - SD / Basic Vinyl DJ set VI: €125

Denon DJ X-1800 & 2 * Denon DJ SC-5000 & 2 * Synq X-TRM I



Pro DJ set VII: €150

Denon DJ X-1800 & 2 * Denon DJ SC-5000 & 2 * Technics SL-1210MK7

